coarse and medium sanding

Trowel-fill

Final cut

Normal Finishing process

Demestic wood species

Apply sealer with Roller or T-Bar (400-500 sqft/gal

LOBA® EasyStart (Dry time 1 hrs.)

Tropical wood species

Apply sealer with Roller or T-Bar (400-500 sqft/gal

LOBA® ExoticSealer (Dry time 1-2 hrs.)

Choose the suitable finish according to its wear resistance:
(Offical Areas (Stores, Restaurants)
LOBA® Supra
Commercial Areas (Schools, Offices)
LOBA® EasyFinish
LOBA® Supra
Light Commercial Areas (Medium Traffic)
LOBA® EasyFinish
LOBA® Viva (with one additional coat extra)
Normal Wear (Residential)
LOBA® WS Viva

Apply first coat of Finish with Roller or T-Bar (325-400 sqtf/gal)

LOBA® Supra
or
LOBA® EasyFinish
or
LOBA® WS Viva
(Dry time: over night)

Screaning with sanding net grid 120

Apply last coat of Finish with Roller or T-Bar (325-400 sqtf/gal)

LOBA® Supra
or
LOBA® EasyFinish
or
LOBA® WS Viva
(Dry time: 2 hrs.)

GlobaSeal System (suitable for almost all wood species, pleas check suitability list.)

Apply LOBA® GlobaSeal with LOBA-TOOL Roller Micro 60-80 on a small area (20-30 sqtf)
(Consumption: 2000 sqft/gal

Buff of access with a brown pad from LOBA

Apply LOBA® GlobaSeal with LOBA-TOOL Roller Micro 60-80 on the next small area , go on till the whole room is done

After the whole floor is done buff is slightly with a green pad

LOBA®
HS GlobaSeal
(Dry time 12 hrs.)

Apply first coat of Finish with Roller or T-Bar (325-400 sqtf/gal)

LOBA® Supra
(Dry time: over night)

Screaning with sanding net grid 120

Apply last coat of Finish with Roller or T-Bar (325-400 sqtf/gal)

LOBA® Supra
(Dry time: 2 hrs.)

Staining

Apply LOBA® Stain with cloth on a small area (20-30 sqtf)
(Consumption: 2000 sqft/gal

Rag off till you get a uniform stain floor

LOBA®
Stain
(Dry time 2 hrs.)

Choose the suitable finish according to its wear resistance:
(Offical Areas (Stores, Restaurants)
LOBA® Supra
Commercial Areas (Schools, Offices)
LOBA® EasyFinish
LOBA® Supra
Light Commercial Areas (Medium Traffic)
LOBA® EasyFinish
LOBA® Viva (with one additional coat extra)
Normal Wear (Residential)
LOBA® WS Viva

Apply first coat of Finish with Roller or T-Bar (325-400 sqtf/gal)

LOBA® Supra
or
LOBA® EasyFinish
or
LOBA® WS Viva
(Dry time: 2 hours

Apply second coat of Finish with Roller or T-Bar (325-400 sqtf/gal)

LOBA® Supra
or
LOBA® EasyFinish
or
LOBA® WS Viva
(Dry time: 2 hours

Screaning with sanding net grid 120

Apply last coat of Finish with Roller or T-Bar (325-400 sqtf/gal)

LOBA® Supra
or
LOBA® EasyFinish
or
LOBA® WS Viva
(Dry time: 2 hrs.)

Recoating of Factory Prefinished Hardwood Floors

Perform adhesion test according to LOBA technical information

Clean the floor to make sure it is free of dust and grease with LOBA® Hardwood Floor Cleaner or LOBA® FloorCleaner Concentrate (or with LOBA® Remover if the floor was treated with care- and maintenance products before)

Apply LOBA® WS 2K Contact with T-Bar or Padco® Trim Pad (400-500 sqft/gal)

LOBA®
WS 2K Contact
(Dry time 1-2 hrs.)

Apply one coat of LOBA® Supra with Roller or T-Bar (325-400 sqtf/gal). Final adhesion will be reached after 5 days.